

Fleetwood Quest 12 volt electrical.

FLEETWOOD 12-VOLT HOUSE AND AUTOMOTIVE SYSTEM This system generally includes: all 12-volt interior lighting fixtures & outlets fresh water pump 12-volt accessories House batteries provide 12-volt DC power. These batteries are not the chassis 12-volt batteries. Power is also provided by a DC converter that operates when the motor home electrical cord is plugged into 120-volt AC power source or by the generator (if equipped). The house batteries are charged by the motor home engine alternator, or by the converter when it is operating. Battery Disconnect (If Equipped) Some accessories or equipment such as clocks, radios or the refrigerator may draw small amounts of current even when turned OFF. For your convenience, your motor home may be equipped with relay operated disconnect circuits. These circuits isolate selected electrical systems from either the chassis or the house batteries. Deactivating the relay(s) will prevent battery discharge which may occur over extended storage periods. During normal use of your motor home the relays must always be in the "on" position. If you plan to store the motor home for an extended period, press the disconnect switches to OFF. Remember to press the switches to ON when you take the motor home out of storage. **./1 NOTE 1 A trouble shooting guide and function manual that explains this system is included with your motor home Owner's Information Package •**